





## RC-7041




### CAUTION

Avoid damage to back cushion when assembling to frame. Do not allow frame to contact back-cushion, place a piece of cardboard between opposite frame arm and back-cushion when installing bolt to connect chair back to frame tube. If frame does not allow for easy assembly call Benchmaster for assistance.



A		2 PCS	E		4 PCS	I		8 PCS
B		2 PCS	F		2 PCS	J		4 PCS
C		1 PC	G		4 PCS	K		8 PCS
D		1 PC	H		2 PCS	L		1 PC



**Optional Accessories** -to order ask your dealer or contact Benchmaster Furniture  
[sales@benchmasterfurniture.com](mailto:sales@benchmasterfurniture.com) 866 774-1400 Toll free 949-502-6779 Fax

